

























## 7.5 Держатели для батареек типа N (UM-5)

<b>Q-1740</b> BH511A BH511D  	<b>Q-1739</b> BH521A BH521B BH521D BH521P  	<b>Q-217</b> BH522A BH522D  	<b>Q-1741</b> BH543A BH543D  
---	---	--	--

## 7.6 Держатели для батареек типа 1/2AA

<b>Q-681</b> BH1/2AA-3S  	<b>Q-680</b> BH1/2AA-2P  	<b>Q-413</b> BHC-CR123A  
--	--	--

## 7.7 Держатели, клеммы для батареек типа 6F22 [крона, 1604A, 1604S, 17R8H-U1]

<b>Q-938</b> BH9VA BH9VD  	<b>Q-1305</b> SBH9VA SBH9VAP SBH9VAS 	<b>Q-2023</b> BH9V-2  	<b>Q-2022</b> BH9V-1A BH9V-1D  	<b>Q-215</b> BS-I 
<b>Q-1582</b> BS-I 	<b>Q-1660</b> BS-M-4A 	<b>Q-269</b> BS-IR 	<b>Q-1698</b> BS-IR 	<b>Q-1659</b> SBS-ER 
<b>Q-216</b> BS-E 	<b>Q-9344</b> BS-TR 	<b>Q-60</b> BS 	<b>Q-9089</b> BS-M-2B 